



BUDGET BROOM CUPBOARD INSTALL INSTRUCTIONS

H: 1800 x W: 800 x D: 420

Please read instructions carefully before assembly as this will save time and prevent damage.

TOOL REQUIRED (Drill, 2mm drill piece, Philips screwdriver, hammer)

ITEMS NOT SUPPLIED: PVA glue, staples/nails to attach the back

CONTENTS OF PACKAGE

- 1 Back 4mm
- 2 Sides
- 1 each Top and Bottom
- 1 Middle divider
- 3 Small Shelves
- 1 Toe kick
- 6 Hafele Softclose Hinges (2 parts)
- 2 128mm Slimbow handles
- Shelf Studs, screws, dowell pieces, feet sliders



and white caps



All sides are pre drilled for easy assembly

SIDES

- Place side on flat surface
- Place glue into dowel holes
- Place pegs in and hammer in
- Place hinges plates & rail holder in & screw into place
- Attached top and bottom onto sides



FIXING TOGETHER

- Turn cabinet onto it's front
- Pre-drill holes for screws for shelves
- Screw shelves into place
- Place white caps on with a hammer



TOE KICK

Screw toe kick into place (3 screws)

(sides and centre from inside unit)

BUDGET BROOM CUPBOARD INSTALL INSTRUCTIONS CONTD.

CENTRE DIVIDE

- Glue divide on top and bottom edges
- Inset divide into unit and screw into place from top and bottom of unit

BACK

- Place back onto unit
- Staple back on



FEET

- Attach sliders to bottom of unit and staple on
- Turn cabinet upright



SHELVES

- Insert Shelf Studs and insert shelves

BUDGET BROOM CUPBOARD INSTALL INSTRUCTIONS CONTD.

DOORS

- Attach hinges to door
- Attach door to unit
- Adjust hinges to align doors



HANDLE

- Attach handles with screws supplied in handle pack.

HINGE ADJUSTMENT

- See attached sheet for adjusting soft close hinges