

WARDROBE UNIT INSTALL INSTRUCTIONS



H: 1950 x W: 900 x D: 470

Please read instructions carefully before assembly as this will save time and damage.

TOOL REQUIRED (Drill, 2mm drill piece, Philips screwdriver, hammer)

ITEMS NOT SUPPLIED: PVA glue, staples/nails to attach the back

CONTENTS OF PACKAGE

- | | | |
|---|------------------------------------|-----|
| 1 | Back | 4mm |
| 2 | Sides | |
| 1 | Shelves | |
| 1 | Toe kick | |
| 6 | Hafele Soft close Hinges (2 parts) | |
| 2 | 128mm Slim bow handles | |
- Shelf Studs, screws, dowel pieces, feet sliders and white caps



All sides are pre-drilled for easy assembly

SIDES

- Place side on flat surface
- Place glue into shelf holes
- Place pegs in
- Place rail holders in & screw
- Place hinges in & screw into place



SHELVES

- Glue shelves on edges
- Attach glued side of shelf to sides of unit



- Place glue on top of shelf edge
- Attached side to top of unit



WARDROBE UNIT INSTALL INSTRUCTIONS CONTD.

- Turn cabinet onto its front
- Predrill holes for screws for shelves
- Screw shelves into place
- Place white caps on with a hammer



TOE KICK

- Screw toe kick into place (3 screws)

BACK

- Place back onto unit



- Staple back on



- Attach sliders to bottom of unit and staple on



- Turn cabinet upright
- Insert rail into place
- Attached access to shelf (handle, shelf studs etc)



WARDROBE UNIT (MS) INSTALL INSTRUCTIONS CONTD.

SHELVES

- Insert Shelf Studs and attached shelf

DOORS

- Attach hinges to door
- Attach door to unit
- Adjust hinges to align doors



HANDLE

- Attach handle

HINGE ADJUSTMENT

- See attached sheet for adjusting soft close hinges